



**WIRED FOR
V, 1Ø**

PowerMaster	
FOR USE WITH: MG, H,J,T OPERATOR WITH CDOMCB BOARD AND CONTACTOR PSC MOTOR	
DATE: 7/30/08	REV. 4
BY: F.S.	MG, H, J, T
CONTROL WIRING DIAGRAM	
WIRING DIAGRAM 6502	
© Copyright PowerMaster 1997 No portion of this diagram may be reproduced without the expressed written permission of the manufacturer.	

NOTE: REMOVE JUMPER FROM COM TO STOP TERMINAL S IF STOP BUTTON IS USED.

INTERNAL INTERLOCK WHEN REQUIRED (BREAKS CIRCUIT WHEN ACTIVATED)

EXTERNAL INTERLOCK (WHEN REQUIRED)